



Dell XPS 12 9Q23 Battery Replacement

This guide will show you how to replace the battery inside the device.

Written By: Kyle Yatsula






TOOLS:

- [T5 Torx Screwdriver](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Battery




- Pop the center cover open on the bottom cover.
- Remove the center screw with a #00 Phillips screwdriver.
- Use a T5 Torx screwdriver for the remaining screws around the edge of the bottom cover.

Step 2




- Carefully remove back panel after all screws have been removed.

Step 3




- After the back panel has been removed, disconnect the battery to prevent electrical shock

Step 4



- Use a Phillips #00 screwdriver to remove the 8 screws that secure the battery.

Step 5 — Remove the battery



- Once all the screws have been removed the battery is now safe to extract

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-09 03:52:11 PM.